PO Box 518 620 Applegate St. Philomath, OR 97370



(541) 929-5650 Fax (541) 929-5277 www.wetlabs.com

## **FLNTU Characterization Sheet**

Date: November 4, 2015 S/N: FLNTURT-1359

## **Chlorophyll Scale Factor**

Chlorophyll concentration expressed in µg/l can be derived using the equation:

CHL ( $\mu$ g/I) = Scale Factor x (Output - Dark Counts)

Dark Counts	Analog		Digital	
	0.066	V	49	counts
Scale Factor (SF)	24	μg/I/V	0.0299	μg/l/count
Maximum Output	4.98	V	4133	counts
Resolution	0.2	mV	1.0	counts
Ambient temperature during calibration	22.3	°C		

## Nephelometric Turbidity Unit (NTU) Scale Factor

Turbidity units expressed in NTU can be derived using the equation:

NTU = Scale Factor x (Output - Dark Counts)

	Analog		Digital	
Dark Counts	0.084	V	50	counts
NTU Solution Value	1.82	V	1466	counts
Scale Factor (SF)	75	NTU/V	0.0921	NTU/count
Maximum Output	4.98	V	4133	counts
Resolution	0.4	mV	1.0	counts
Ambient temperature during calibration	22.3	°C		

## **Definition of terms:**

Dark Counts: Signal output of the meter in clean water with black tape over detector.

NTU Solution Value: Signal output of the turbidity sensor when measuring a sample of interest.

**SF (CHL)**: Determined using the following equation:  $SF = x \div (\text{output - dark counts})$ , where x is the concentration of the solution used during instrument characterization. SF is used to derive instrument output concentration from the raw signal output of the fluorometer.

**SF (NTU)**: Scale factor is determined using the following equation:  $SF = xx \div (Output - Dark counts)$ , where xx is the value of a Formazin concentration. For example:  $12.2 \div (2011 - 50) = 0.0062$ .

Maximum Output: Maximum signal output the fluorometer is capable of.

Resolution: standard deviation of 1 minute of collected data.

FLNTURT-1359 fIntuchar Revision H 10/2/07